



NOTES:

1. LEAD FLANGE MUST BE SET IN APPROVED FLASHING CEMENT. HEAT FUSED APPLICATIONS SHOULD SET IN SOFTENED MEMBRANE.
2. LEAD FLASHING SHOULD CARRY OVER AND INTO VENT PIPE OPENING 1 INCH.

VENT PIPE FLASHING
with LEAD SLEEVE

NUMBER:
PG-PEN-002

DATE:
July 2011



Polyglass USA, Inc.
1111 W. Newport Center Dr.
Deerfield Beach, FL 33442
www.polyglass.com